

## Guide Formulation

**Loose Face Powder with SIPERNAT® 22 S and SPHERILEX® 10 PC**

The SIPERNAT® carrier concept is used to convert liquids into powder. Mixing powder with powder, that's the easy way. A make-up for a velvet skin feel and with matt effect all day long.

PHASE	INGREDIENTS	INCI NAME	%	FUNCTION
1	Talc	Talc	76.30	Filler
	Magnesium stearate	Magnesium stearate	2.60	Filler
	Unipure brown LC 881	CI 77499 (and) CI77491 (and) CI 77492	3.40	Pigments
	Unipure white LC 981	CI 7891	0.10	Pigments
2	<b>SIPERNAT® 22 S</b>	<b>Hydrated silica</b>	<b>2.50</b>	<b>Carrier</b>
	TEGOSOFT® OER MB	Oleyl erucate	5.00	Emollient
	Oxynex K liquid	PEG-8 (and) Tocopherol (and) Ascorbyl Palmi-tate (and) Ascorbic Acid (and) Citric Acid	0.10	Antioxidant
3	<b>SPHERILEX® 10 PC</b>	<b>Hydrated silica</b>	<b>10.00</b>	<b>Sensory additive, Matt effect</b>
<b>Total</b>			<b>100.00</b>	

HPC 1862/1

**PROCESSING**

- Mix phase 1 and grind until homogeneous.
- Mix liquid ingredients of phase 2. Add dropwise onto the SIPERNAT® 22 S while gently mixing.
- Mix all phases until uniformly blended.

**NOTE:** All formulations have been subjected to stability tests and have been shown to perform well. However, formulators should always perform their own stability tests when adapting formulations and / or using raw materials from other sources.

## Guide Formulation

**Loose Face Powder with SIPERNAT® 22 S and SPHERILEX® 10 PC****Disclaimer**

This information and any recommendations, technical or otherwise, are presented in good faith and believed to be correct as of the date prepared. Recipients of this information and recommendations must make their own determination as to its suitability for their purposes. In no event shall Evonik assume liability for damages or losses of any kind or nature that result from the use of or reliance upon this information and recommendations. EVONIK EXPRESSLY DISCLAIMS ANY REPRESENTATIONS AND WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, AS TO THE ACCURACY, COMPLETENESS, NON-INFRINGEMENT, MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE (EVEN IF EVONIK IS AWARE OF SUCH PURPOSE) WITH RESPECT TO ANY INFORMATION AND RECOMMENDATIONS PROVIDED. Reference to any trade names used by other companies is neither a recommendation nor an endorsement of the corresponding product, and does not imply that similar products could not be used. Evonik reserves the right to make any changes to the information and/or recommendations at any time, without prior or subsequent notice.

AEROSIL®, SIPERNAT® and SPHERILEX® are registered trademarks of Evonik Industries AG or one of its subsidiaries.

EUROPE / MIDDLE EAST /  
AFRICA / LATIN AMERICA

**Evonik Operations GmbH**  
Business Line Silica  
Rodenbacher Chaussee 4  
63457 Hanau  
Germany

Phone +49 6181 59-12532  
Fax +49 6181 59-712532

ask-si@evonik.com  
www.silica-specialist.com

## NORTH AMERICA

**Evonik Corporation**  
Business Line Silica  
299 Jefferson Road  
Parsippany, NJ 07054-0677  
USA

Phone +1 800 233-8052  
Fax +1 973 929-8502

ask-si-nafta@evonik.com

## ASIA PACIFIC

**Evonik (SEA) Pte. Ltd.**  
Business Line Silica  
3 International Business Park  
#07-18, Nordic European Centre  
Singapore 609927

Phone +65 6809-6877  
Fax +65 6809-6677

ask-si-asia@evonik.com