

## Guide Formulation

NO SHINE LIQUID-TO-POWDER PRIMER WITH  
AEROSIL® R 812 S AND SPHERILEX® 10 PC

This liquid serum absorbs sebum and gives a pronounced powdery sensation.

This specific sensory feeling is achieved due to the high concentration of SPHERILEX® 10 PC.

The addition of AEROSIL® R 812 S improves the transformation from liquid to powder.

Phase	Ingredients	INCI Name	% w/w	Function
<b>A</b>	Demin. Water	Aqua	71.85	Solvent
	Acnacidol BG Biofunctional	Butylene Glycol, 10-Hydroxydecanoic Acid, Sebacic Acid	3.00	Active ingredient
	Texturpure SA-1	Hydroxypropyl Methylcellulose, Cellulose Gum, Xanthan Gum	1.00	Thickening/ suspending agent
	Dissolvine GL-47 S	Tetrasodium Glutamate Diacetate, Aqua	0.30	Chelating agent
<b>B</b>	Euxyl PE 9010	Phenoxyethanol, Ethylglycerin	1.00	Preservative
	Isopenyldiol	Isopentyldiol	0.50	Humectant
	Softisan GC8	Glyceryl Caprylate	0.50	Multifunctional ingredient
<b>C</b>	SPHERILEX® 10 PC	Hydrated Silica	5.50	Absorbent
<b>D</b>	Ronaflair Flawless	Silica, CI77891; CI77491	5.00	Opacifying agent
<b>E</b>	AEROSIL® R 812 S	Silica Silylate	0.20	Absorbent
<b>F</b>	Alcohol. Dent.	Alcohol	10.00	Solvent
<b>E</b>	LINCOL ORH 40 S	PEG-40 Hydrogenated castor oil	1.00	Solubilizer
	Parfum	Parfum	0.10	Fragrance
<b>F</b>	Lactic Acid 80%	Lactic Acid, Aqua	0.05	Buffering agent

Developed by Eigenmann & Veronelli Italy

**NOTE:** All formulations have been subjected to stability tests and have been shown to perform well. However, formulators should always perform their own stability tests when adapting formulations and / or using raw materials from other sources.

## PROCESSING

- Add Texturpure SA-1 to the water while stirring.
- Add Dissolve GL-47 S and keep stirring for additional 20 minutes.
- Add Acnacidol BG and stir for 5 minutes.
- Mix all ingredients of Phase B until homogeneous mixture is obtained.
- Add Phase B to Phase A while stirring and homogenize.
- Add the powders (Phases C-E) and the alcohol one by one while stirring.
- Mix all ingredients of Phase G until homogenous mixture is obtained.
- Add Phase G to the mixture while stirring and homogenize.
- Adjust pH value with Lactic Acid.

### EUROPE / MIDDLE EAST / AFRICA / LATIN AMERICA

#### Evonik Operations GmbH

Silica business line

Rodenbacher Chaussee 4

63457 Hanau-Wolfgang

Germany

Phone +49 6181 59-12532

Fax +49 6181 59-712532

[ask-si@evonik.com](mailto:ask-si@evonik.com)

[www.silica-specialist.com](http://www.silica-specialist.com)

### AMERICAS

#### Evonik Corporation

Silica business line

2 Turner Place

Piscataway, NJ 08804

USA

Phone +1 732 981-5000

[ask-si-america@evonik.com](mailto:ask-si-america@evonik.com)

### ASIA PACIFIC

#### Evonik (SEA) Pte. Ltd.

Silica business line

3 International Business Park

#07-18, Nordic European Centre

Singapore 609927

Phone +65 6 809-6851

Fax +65 6 809-6651

[ask-si-asia@evonik.com](mailto:ask-si-asia@evonik.com)

This information and any recommendations, technical or otherwise, are presented in good faith and believed to be correct as of the date prepared. Recipients of this information and recommendations must make their own determination as to its suitability for their purposes. In no event shall Evonik assume liability for damages or losses of any kind or nature that result from the use of or reliance upon this information and recommendations. EVONIK EXPRESSLY DISCLAIMS ANY REPRESENTATIONS AND WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, AS TO THE ACCURACY, COMPLETENESS, NON-INFRINGEMENT, MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE (EVEN IF EVONIK IS AWARE OF SUCH PURPOSE) WITH RESPECT TO ANY INFORMATION AND RECOMMENDATIONS PROVIDED. Reference to any trade names used by other companies is neither a recommendation nor an endorsement of the corresponding product, and does not imply that similar products could not be used. Evonik reserves the right to make any changes to the information and/or recommendations at any time, without prior or subsequent notice.

**AEROSIL®** and **SPHERILEX®** are registered trademarks of Evonik Industries or its subsidiaries.

**The Silica specialists at Evonik - Inside, to get it right.**